

# Air-Con Monitor Advanced Quick Start Guide v3-14

## First Power Up

For best results use Alkaline AA batteries or better to ensure long life. Please do not use rechargeable batteries. When the unit is powered up for the first time the **RED** LED remains illuminated for 15 seconds and then stops for 3 seconds. During this time the PIR is being allowed to settle to avoid any false triggers.

*This means the unit cannot be interacted with for 20 seconds.*

## Opening the unit for viewing LED's, battery installation.

To open the unit unscrew the bottom and lift up to release for access to the battery compartment, setup LEDs. Please Make sure when inserting batteries the - (negative) side of the batteries make contact with the springs. When programming with the button you will be able to easily view the LED's with the top removed. When closing the top locate the top notches then lower in place and screw back. Be careful not to bend the raised IR transmitter LED.

## Setup

*If the unit is not interacted with for 15 seconds it will come out of the setup mode saving any settings you have put in up to that point.*

A quick Press of the black set up button (red arrow) will start the first set up mode.



### Setup Mode 1

The **RED** Led flashes **once**.

**This stores the OFF command from your air-con remote control.**

First make sure your air-con remote control is on (as you would do when switching on your air-con unit)

Then do a short button press which will turn on the **GREEN** LED, now the monitor is waiting for the off command from your air-con remote control, point your air-con remote control at the monitor and press the off button, you will see the **GREEN** LED turn off to indicate that it has stored the off command.

(If the button is pressed and no off command is received after around 5 seconds the unit will timeout and you will need to do another short press to turn the green led on again)



To move to the next mode press and hold the button **until you see 2 RED flashes** and release.

### Setup Mode 2

The **RED** Led flashes **2 times**.

You can test your OFF command is switching off your air-con from here by a short button press. The command is sent once per button press. The **GREEN** LED will flash when the command is transmitted.

To move to the next mode press and hold the button **until you see 3 RED flashes** and release.

### Setup Mode 3 - You can also set this up via the PC software

The **RED** Led flashes **3 times**.

**This sets the amount of time that elapse when no movement is detected before sending the off command.**

A short button press changes the flashing **GREEN** LED. Each short press will increase the number of flashes up to 4 flashes. Each **GREEN** flash indicates the following:-

- 1 **GREEN** flash = switch off the air-con if no movement is detected for **15 mins**
- 2 **GREEN** flashes = switch off the air-con if no movement is detected for **30 mins**
- 3 **GREEN** flashes = switch off the air-con if no movement is detected for **60 mins**
- 4 **GREEN** flashes = OFF the monitor movement sensor is disabled.

To move to the next mode press and hold the button **until you see 4 RED flashes** and release.

#### **Setup Mode 4** - You can also set this up via the PC software

The **RED** Led flashes **4 times**.

**This will enable or disable the light sensor to stop the off command being sent when it is dark.**

A short button press turns on the **GREEN** LED. Each short press will turn this on or off.

**GREEN** LED on – Light sensor enabled.

**GREEN** LED off – Light sensor disabled.

To move to the next mode press and hold the button **until you see 5 RED flashes** and release.

#### **Setup Mode 5**

The **RED** Led flashes **5 times**.

**This stores the UP TEMP command from your air-con remote control.**

First make sure your air-con remote control is on (as you would do when switching on your air-con unit)

Then do a short button press which will turn on the **GREEN** LED, now the monitor is waiting for the Up Temperature command from your air-con remote control, point your air-con remote control at the monitor and press the Up Temperature button, you will see the **GREEN** LED turn off to indicate that it has stored the UP Temperature command.

(If the button is pressed and no command is received after around 5 seconds the unit will timeout and you will need to do another short press to turn the green led on again)

To move to the next mode press and hold the button **until you see 6 RED flashes** and release.

#### **Setup Mode 6**

The **RED** Led flashes **6 times**.

You can test your Up Temperature command by a short button press. The command is sent once per button press. The **GREEN** LED will flash when the command is transmitted.

To finish set up press the button until the RED LEDs go out and release, or wait 15 seconds for the unit to automatically come out of the setup mode.

We would suggest you setup the off command and the Temp Up command first using the button, then connect the USB to setup the other options on the PC software to make sure you don't unintentionally override any settings manually by using the button after setting up via the PC software.

#### **Sighting the Monitor**

The monitor needs to be able to send the IR signal to the unit in the same way as the remote control, so needs to be preferably in line of sight. You can test this by sending the off signal test from where you plan to site the unit.

*After installation if you are testing the non-movement delay time to switch off, please make sure the monitor sees movement in the room first, this wakes up the monitor to activate the delay timer to send the off command.*

For more detailed information please refer to the manual.

#### **Limited Warranty**

Seller warrants to the original consumer purchaser of this product that, for a period of one year from the date of purchase, this product will be free from defects in material and workmanship and will perform in substantial conformity to the description of the product in this User's Manual. This warranty shall not apply to defects or errors caused by misuse or neglect. If the product is found to be defective in material or workmanship, or if the product does not perform as warranted above during the warranty period, Seller will either repair it, replace it or refund the purchase price, at its option, upon receipt of the product at the address below, postage prepaid, with proof of the date of purchase and an explanation of the defect or error. The repair, replacement, or refund that is provided for above shall be the full extent of Seller's liability with respect to this product. For repair or replacement during the warranty period, call Eco-energysavers customer service to receive Return Authorisation number, properly package the product (with the Return Authorization number clearly printed on the outside of the package) and send the product, along with all other required materials, to Eco-energysavers, Charter House, The Square, Bideford, Devon, EX39 6BL. Tel: +44 117 230 3776